

Updated Application Instructions

PRE-CLEANING DEVICE SCREEN

- Step 1** Thoroughly scrub all glass surfaces with the Cleaner wipe supplied in Sachet 1. If any form of screen protector had previously been applied to the glass, then make sure **all traces** of adhesive residue have completely been removed.
- Step 2** Allow device to completely dry.
- Step 3** Ensure you remove all traces of the cleaner by buffing the glass thoroughly with the microfiber towel supplied.

Any adhesive residue or cleaner trace left on the glass surface will adversely affect the ability of LiquidNano to bond to the glass.

APPLYING THE LIQUIDNANO COATING

For optimal results, apply LiquidNano to your mobile device last thing at night to allow maximum curing time.

- Step 1** In a circular motion, apply LiquidNano to all glass surfaces using the coating wipe supplied in Sachet 2. Apply coating until supplied wipe feels dry.
- Step 2** Allow glass surface to cure **for at least 30 minutes**. For best results please allow surface to cure overnight.
- Step 3** Once cured remove any excess residue with the microfiber towel supplied.

POST APPLICATION

Following the application of LiquidNano you may notice that some minor scratching appears on your device. Please do not be concerned as this scratching is in a layer of excess liquid glass remaining on your screen after application. This scratching is easily buffed off using the microfiber cloth supplied. Your device screen remains protected by the Nano surface layer at all times.

If at any time, prior to, or after application of LiquidNano, you have any questions then please email info@liquidnano.com and we will be happy to answer your queries directly.